

Renia

ORTEC

Multi Purpose Cement

INSTRUCTIONS

All materials which are used in the O&P market as leather, rubber, TR, PUR, EVA, Crepe, Textiles and others can be bonded. **RENIA ORTEC** will also work on PP, PE (foam) and Metal.

Women can also work with **RENIA ORTEC** because it is toluene free.

PREPARATION

All materials should be sanded and cleaned first. Apply **RENIA ORTEC** on both sides, porous materials sometimes need a second coating. Greasy surfaces should be cleaned with acetone or thinner.

If **RENIA ORTEC** becomes too thick, use **RENIA** thinner.

OPEN TIME

10 to 60 minutes. With heat faster. Can also be reactivated when heated.

STORAGE

Minimum 12 months at room temperature. No separation !

Open time 10 to 60 minutes



A. Algeo Ltd
Sheridan House
Bridge Industrial Estate
Speke Hall Road
Liverpool, L24 9HB.

t: 0151 448 1228 e: sales@algeos.com